



A: Angiver rørdiameter
Indicates duct diameter
B: Angiver diameter slangekobling
Indicates diameter hose coupling

Klapventil

Konisk, montering
indvendig i rør

Flap valve

with conical entry for
inserting into the duct

ø udv. A,B Ext. dia. A,B	ø udv. A,B Ext. dia. A,B
050-050	076-063
063-050	076-076
063-063	



A: Angiver rørdiameter
Indicates duct diameter
B: Angiver diameter slangekobling
Indicates diameter hose coupling

Klapventil med kontakt

Konisk, montering
indvendig i rør

Flap valve with switch

with conical entry for
inserting into the duct and
mechanical microswitch

ø udv. A,B Ext. dia. A,B	ø udv. A,B Ext. dia. A,B
050-050	076-063
063-050	076-076
063-063	



A: Angiver tilslutning til klapventil
Indicates the connection to
the flap valve
B: Angiver slangediameter
Indicates the hose diameter

Slangekobling

For tilslutning til klapventil

Hose coupling

for mounting on hoses,
combine with flap valve

ø udv. A,B Ext. dia. A,B	ø udv. A,B Ext. dia. A,B
050-038	076-050
050-050	076-063
063-050	076-076
063-063	



Tæt luftafbryder

Med pneumatik, glat

Pneumatic sliding damper

with smooth edge

Diameter	Diameter
050	108
063	127
076	152
102	



Tæt luftafbryder

Glat

**Manual tight
sliding damper**

with smooth edge

Diameter	Diameter
050	108
063	127
076	152
102	